

# RELEASE NOTES

**Product Name: Honeywell Safety Suite**

**Device Configurator Version: V2.8.0**

**Operating System: Windows 10 (x64) version 1809 or above**

**Intel® Wireless Bluetooth® Driver: 21.60.0 or above**

**Microsoft® .NET Framework v4.7.2 or above**

**Release Date: Aug 2020**

## **WHAT'S NEW**

This release supports the following features:

### **1. Latest Firmware Support**

This release adds support for the latest firmware for the supported devices.

### **2. Database Upgrade**

The Sql Server Express database has been upgraded to the latest version.

## **INSTALLATION AND UPDATE NOTES**

### **Before Installation:**

Close all other programs.

### **Installation:**

1. Download the software from the Honeywell Safety Suite [website](#).
2. Launch the installer by double-clicking the installation file.
3. Follow the instructions for installation. The initial installation can take between 15 and 20 minutes.
4. Once the software is successfully installed, an "Installed Successfully" message is displayed. Click the "FINISH" button to exit the installation program or click the "LAUNCH APPLICATION" button to exit the installation program and launch Honeywell Safety Suite Device Configurator.

## SUPPORTED INSTRUMENTS AND FIRMWARE

### BW PRODUCTS

NO.	INSTRUMENT	FIRMWARE VERSION
1	IntelliDoX	12.000
2	MicroDock II	N/A
3	BW Clip & BW Clip Real Time	2.101
4	BW ICON	1.00
5	BW Max XT II	13.000
6	BW MicroClip XL & BW MicroClip X3	50D
7	BW Quattro	4.000
8	BW Solo	1.060
9	BW Ultra	1.018
10	GasAlertMicro 5	N/A
11	GasAlert Extreme	N/A

### RAE SYSTEM PRODUCTS

NO.	INSTRUMENT	FIRMWARE VERSION
1	AutoRAE 2 Controller	1.38
2	AutoRAE Cradle for Handheld PID Monitor	1.38
3	AutoRAE 2 Cradle for MicroRAE	1.38
4	AutoRAE 2 Cradle for MultiRAE	1.38
5	AutoRAE 2 Cradle for QRAE 3	1.38
6	AutoRAE 2 Cradle for ToxiRAE Pro	1.38
7	AreaRAE Plus & AreaRAE Pro	1.08
8	MicroRAE	1.16
9	MiniRAE 3000 + & MiniRAE Lite +	2.22
10	MultiRAE, MultiRAE Benzene, MultiRAE Lite, & MultiRAE Pro	1.52
11	MultiRAE WingTank	1.50W
12	ppbRAE 3000 +	2.22
13	QRAE 3	2.16A
14	ToxiRAE Pro, ToxiRAE Pro CO2, ToxiRAE Pro LEL, ToxiRAE Pro PID	1.84B
15	UltraRAE 3000 +	2.22

### KNOWN ISSUES AND WORKAROUNDS

NO.	ISSUE	WORKAROUND
1	The device connectivity status is not reflected correctly after a device is connected or disconnected from the computer or the network.	Manually refresh the Device list using the Refresh button on the device inventory page within the software.
2	The correct firmware version is not displayed after the device firmware has been updated.	Manually refresh the Device list using the Refresh button on the device inventory page within the software and navigate to the device details page to view the correct firmware version.
3	The software does not allow the device firmware to be downgraded while it is connected to the network.	Relaunch the software after disconnecting the computer from the network and manually upload the previous version of the firmware to the device.
4	After changing the short date format, the new date format is not reflected in the software.	Close and re-launch the application, or logout and re-login to view the date format change.

## PREVIOUS VERSIONS

### Honeywell Safety Suite Device Configurator v2.7.0

#### What's New

- 1. BW Icon Support**  
This release adds support for BW Icon over IR, BLE and IntelliDoX.
- 2. Certificate Customization**  
Customers can now customize the Bump and Calibration Certificates.
- 3. PCB Serial No Update**  
The software now supports the update of Serial Number for replacement PCBs.

### Honeywell Safety Suite Device Configurator v2.6.0

#### What's New

- 1. BW Solo BLE Support**  
BW Solo devices can now connect to the software over BLE
- 2. Software Update Notification**  
The user will be notified if a new version of the software is available for download.

### Honeywell Safety Suite Device Configurator v2.5.0

#### What's New

- 1. Schedule Data Log Export**  
The software now allows bulk export of data logs based on user-defined schedule.
- 2. Clear AutoRAE 2 Dock Data**  
After successfully downloading the data from the dock, the software can now be configured to clear the dock memory card to expedite future downloads.
- 3. Configure Proxy Server**  
Internet connectivity can now be enabled using Proxy Server in case direct connectivity is not available which will allow users to download the latest device firmware using the software.

### Honeywell Safety Suite Device Configurator v2.4.0

#### What's New

- 1. Data Views**  
The customer can now access consolidated Data Logs, Event Logs, Bump and Calibration Results through simple tabular views. The data can also be exported in excel format.
- 2. Revamped Device List View**  
The device list has been updated to include Last Download, Last Calibration & Last Bump Test Date. In addition, the most commonly used tasks have been added to a ribbon bar at the top of the page.
- 3. Bulk Update Device Parameters**  
The users are now able to set location and status across multiple devices simultaneously.
- 4. Excel Report Output**  
The software now allows all reports to be exported in excel format.

## **Find out more**

For more information visit:

<https://safety.honeywell.com/en-us/software-and-services/connected-safety/safety-suite>

## **Europe, Middle East, Africa**

[gasdetection@honeywell.com](mailto:gasdetection@honeywell.com)

## **Americas**

[detectgas@honeywell.com](mailto:detectgas@honeywell.com)

## **Asia Pacific**

[analytics.ap@honeywell.com](mailto:analytics.ap@honeywell.com)

## **Technical Support**

[support.safetysuite@honeywell.com](mailto:support.safetysuite@honeywell.com)

1-833-556-3515

Microsoft and Windows are trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries. All other trademarks are the property of their respective owners.

Note: Due to ongoing research and product improvement, specifications are subject to change without notice.

Safety Suite Device Configurator Release Notes | Rev H | 02/20  
© 2020 Honeywell International Inc.

**Honeywell**